

# ZS6KMD 40M TRAVEL DIPOLE (QRP)

- ① Use 2mm Alkerm Pipecord.  
Cut to length using standard Formula 4ES / F Mk2
- ② Use a large coat button for the center piece. Drill a hole and make a loop to hang it.
- ③ Drill 2 holes for a cable tie to hold the RG216 to the button.
- ④ End egg insulators can be made using other buttons or off cut Resrex. If Resrex is used it makes an ideal device to wrap the antenna leads onto.
- ⑤ Ball up and put in ziploc lunch packet until you need it (use with ZS4U Superfix)

